

Van Running Boards

Note: Full flare van running boards will not work with sliding side doors, only cargo doors

CHEVY	Part #	Year	Wheelbase			Type
Full size	26104	78-95	110" Short Wheelbase		Tail	Full Flare
	11104	78-95	135" Standard		Tail	Full Flare
	11196	96-02	135" Standard		Tail	Full Flare
	511496	96-02	155" Extended		Tail	Full Flare
	11193	03+	135" Standard	3 door	Tail	Full Flare
	11103	03+	135" Standard	4 door	Tail	Full Flare
	511496-03	03+	155" Extended	3 door	Tail	Full Flare
Mini Van	14700	95-	Astro Extended		Tail (will not fit with cladding)	Full Flare
FORD						
Full size	13100	75-91	138" Standard		No Tail (will also fit extended van)	Full Flare
	13000	92-07	138" Standard		No Tail (will also fit extended van)	Full Flare
	13104	92-07	138" Standard		Tail (will not fit extended van)	Full Flare
	ss13104	92-07	138" Standard		Tail	Pony
	13399	92-07	Class "C" for cutoff chassis		No Tail	Full Flare
	13109	92-07	Extended w/ extra wide pass step area		Tail (extended van only)	Full Flare
	13108	08+	Standard		No Tail (will also fit extended van)	Full Flare
	13111	08+	Standard		Tail (will not fit extended van)	Full Flare
	13112	08+	Standard (Inlaid w/ one long step)		Tail (will also fit extended van)	Full Flare
	13110	08+	Extended w/ extra wide pass step area		Tail (extended van only)	Full Flare
DODGE						
Full size	27104	94-98	109" Short		Tail	Full Flare
	27105	99-03	109" Short		Tail	Full Flare
	12104	94-03	127" Standard		Tail (will not fit extended)	Full Flare
	12106	94-03	127" Standard		No Tail (will also fit extended)	Full Flare
Sprinters	12586	2003-06	158" w/ extra wide pass step area		Tail	Full Flare
	913074ew	07+	170" w/ extra wide pass step area		No Tail	Pony
	12144	07+	144"		Optional Tail	Pony
	12170	07+	170"		Optional Tail	Pony